





## TENOR SAXOPHONE MUTE


*with a shoulder belt*



Attach the shoulder belt to the two D-rings on the mute, passing it behind the handle and adjust its length with the sliders (1)



Take the Saxmute on,  
Fine tune the shoulder belt length  
Attach the saxophone to the Z-hook (2)  
inside the mute,



The suspension string length can be adjusted:  
Pull the free end (3) of the string to lift the hook up  
Pull one of the other ends (4) to lower the hook

*with a PA speaker stand*

